




Overdrive Planetary Gear, Overdrive Direct Clutch and Overdrive One-Way Clutch


COMPONENTS



DISASSEMBLY OF OVERDRIVE PLANETARY GEAR, OVERDRIVE DIRECT CLUTCH AND OVERDRIVE ONE-WAY CLUTCH

- CHECK OPERATION OF ONE-WAY CLUTCH**
Hold the O/D direct clutch drum and turn the input shaft. The input shaft turns freely clockwise and locks counter-clockwise.
- REMOVE OVERDRIVE DIRECT CLUTCH ASSEMBLY FROM OVERDRIVE PLANETARY GEAR**





3. CHECK PISTON STROKE OF OVERDRIVE DIRECT CLUTCH

- (a) Place the oil pump onto the torque converter, and then place the O/D direct clutch assembly onto the oil pump.

- (b) Using SST and a dial indicator, measure the O/D direct clutch piston stroke applying and releasing the compressed air (4 – 8 kg /cm², 57 – 114 psi or 392–785 kPa) as shown.



SST 09350-30020 (09350-06120)

Piston stroke:

22R-E: 1.77 – 2.07 mm (0.0697 – 0.0815 in.)

Others: 1.85 – 2.15 mm (0.0728 – 0.0846 in.)

If the values are nonstandard, inspect the discs.




4. REMOVE FLANGE, PLATE(S) AND DISC(S)

- (a) Remove the snap ring from the O/D direct clutch drum.
- (b) Remove the flange, plates and discs.

HINT:

22R-E: One flange, one plate and one disc

Others: One flange, two plates and two discs




5. REMOVE PISTON RETURN SPRING

- (a) Place SST on the spring retainer and compress the return spring with a shop press.


SST 09350-30020 (09350-07040)

- (b) Using snap ring pliers, remove the snap ring.
- (c) Remove the piston return spring.




6. REMOVE OVERDRIVE DIRECT CLUTCH PISTON

- (a) Place the oil pump onto the torque converter and then place the O/D direct clutch onto the oil pump.
- (b) Hold the O/D direct clutch piston with hand, apply compressed air to the oil pump to remove the O/D direct clutch piston.
- (c) Remove the O/D direct clutch piston.
- (d) Remove the two O-rings from the piston.




7. REMOVE RING GEAR FLANGE

(a) Remove the snap ring.




(b) Remove the ring gear flange.




8. REMOVE RETAINING PLATE


(a) Remove the snap ring.




(b) Remove the retaining plate.




9. REMOVE OVERDRIVE ONE-WAY CLUTCH WITH OUTER RACE



10. REMOVE ONE-WAY CLUTCH FROM OUTER RACE



11. REMOVE THRUST WASHER




INSPECTION OF OVERDRIVE PLANETARY GEAR AND OVERDRIVE DIRECT CLUTCH

1. INSPECT DISC, PLATE AND FLANGE

Check to see if the sliding surface of the disc, plate and flange are worn or burnt. If necessary, replace them.


HINT:

- If the lining of the disc is peeling off or discolored, or even if parts of the printed numbers are defaced, replace discs.
- Before assembling new discs, soak them in ATF for at least fifteen minutes.



2. CHECK OVERDRIVE DIRECT CLUTCH PISTON

- Check that check ball is free by shaking the piston.
- Check that the valve does not leak by applying low pressure compressed air.




3. CHECK OVERDRIVE DIRECT CLUTCH DRUM BUSHINGS

Using a dial indicator, measure the inside diameter of the clutch drum bushings.

Maximum inside diameter: 27.11 mm (1.0673 in.)

If the inside diameter is greater than the maximum, replace the clutch drum.




4. CHECK OVERDRIVE PLANETARY GEAR BUSHING

Using a dial indicator, measure the inside diameter of the planetary gear bushing.

Maximum inside diameter: 11.27 mm (0.4437 in.)

If the inside diameter is greater than the maximum, replace the planetary gear.




5. MEASURE PLANETARY PINION GEAR THRUST CLEARANCE

Using a feeler gauge, measure the planetary pinion gear thrust clearance:

Standard clearance: 0.20 – 0.60 mm (0.0079 – 0.0236 in.)

Maximum clearance: 1.00 mm (0.0394 in.)


If the clearance is greater than the maximum, replace the planetary gear assembly.



ASSEMBLY OF OVERDRIVE PLANETARY GEAR, OVERDRIVE DIRECT CLUTCH AND OVERDRIVE ONE-WAY CLUTCH


1. INSTALL THRUST WASHER TO OVERDRIVE PLANETARY GEAR

Install the thrust washer to the overdrive planetary gear, the grooved side facing upward.




2. INSTALL OVERDRIVE ONE-WAY CLUTCH

(a) Install the one-way clutch into the outer race, the flanged side of the one-way clutch facing upward.




(b) Install the overdrive one-way clutch with the outer race to the overdrive planetary gear.



AT8146


3. INSTALL RETAINING PLATE

(a) Install the retaining plate.



AT8135


(b) Install the snap ring.



AT8134


4. INSTALL RING GEAR FLANGE TO OVERDRIVE PLANETARY RING GEAR

(a) Install the ring gear flange as shown.



AT8133

(b) Install the snap ring.




AT8144

5. INSTALL OVERDRIVE DIRECT CLUTCH PISTON


(a) Coat new O-rings with ATF and install them on the O/D direct clutch piston.

(b) Being careful not to damage the O-rings, press in the direct clutch piston into the clutch drum with both hands.



6. INSTALL PISTON RETURN SPRING


(a) Install the piston return spring to the piston.



(b) Place SST on the spring retainer, and compress the return spring with a shop press.

SST 09350-30020 (09350-07040)

(c) Install the snap ring with a screwdriver. Be sure the end gap of the snap ring is not aligned with the spring retainer claw.




7. INSTALL PLATE(S), DISC(S) AND FLANGE

(a) Install the plates and discs.


Install in order: P = Plate D = Disc

22R-E: P-D



Others: P-D-P-D



(b) Install the flange, the flat end facing downward.



(c) Install the snap ring.



8. CHECK PISTON STROKE OF OVERDRIVE DIRECT CLUTCH

(a) Place the oil pump onto the torque converter, and then place the O/D direct clutch assembly onto the oil pump.

(b) Using SST and a dial indicator, measure the overdrive direct clutch piston stroke applying and releasing the compressed air (4 – 8 kg/cm², 57 – 114 psi or 392 – 785 kPa) as shown.

SST 09350-30020 (09350-06120)

Piston stroke:


22R-E: 1.77 – 2.07 mm (0.0697 – 0.0815 in.)

Others: 1.85 – 2.15 mm (0.0728 – 0.0846 in.)

If the piston stroke is less than the limit, parts may have been assembled incorrectly, check and reassemble again. If the piston stroke is nonstandard, select another flange.


HINT: There are six different thicknesses for the flange.

Flange thickness		mm (in.)	
No.	Thickness	No.	Thickness
16	3.6 (0.142)	19	3.3 (0.130)
17	3.5 (0.138)	20	3.2 (0.126)
18	3.4 (0.134)	21	3.1 (0.122)



9. INSTALL OVERDRIVE DIRECT CLUTCH ASSEMBLY

- (a) Align the flukes of discs in the direct clutch.
- (b) Install the direct clutch assembly onto the O/D planetary gear.



10. CHECK OPERATION OF ONE-WAY CLUTCH

Hold the O/D direct clutch drum and turn the input shaft. The input shaft turns freely clockwise and locks counter-clockwise.