




## Transfer Chain Rear Case


### COMPONENTS



### DISASSEMBLY OF TRANSFER CHAIN REAR CASE

1. **REMOVE FRONT OUTPUT SHAFT OIL SEALS**  
Using a screwdriver and hammer, drive out the two oil seals.
2. **REMOVE FRONT OUTPUT SHAFT BEARING**
  - (a) Using snap ring pliers, remove the snap ring.
  - (b) Remove the bearing.






### 3. REMOVE FRONT DRIVE SHAFT BEARING


Using SST and a press, press out the bearing.

SST 09608-12010 (09608-00020, 09608-00040)



### 4. REMOVE OIL STRAINER

Remove the four bolts and strainer from the chain rear case.



## ASSEMBLY OF TRANSFER CHAIN REAR CASE



### 1. INSTALL OIL STRAINER

(a) Apply sealant to 2 or 3 threads of the bolt end.

Sealant: Part No. 08833 – 00070, THREE BOND 1324 or equivalent

(b) Install the oil strainer with the four bolts.

Torque: 70 kg-cm (61 in.-lb, 6.9 N-m)




### 2. INSTALL FRONT DRIVE SHAFT BEARING

Using SST, press in the bearing.


SST 09608-12010 (09608-00020, 09608-00040)

Bearing depth: 1.2 – 1.8 mm (0.047 – 0.071 in.)



### 3. INSTALL FRONT OUTPUT SHAFT BEARING

- (a) Install the bearing to the transfer chain rear case.
- (b) Using snap ring pliers, install the snap ring.



### 4. INSTALL FRONT OUTPUT SHAFT OIL SEALS

- (a) Using SST and a hammer, drive in a new rear oil seal.

SST 09608-32010 and 09608-35014 (09608-06020)

**Oil seal depth: 11.0 - 11.3 mm (0.433 - 0.445 in.)**

- (b) Using SST and a hammer, drive in a new front oil seal.

SST 09608-32010 and 09608-35014 (09608-06020)

**Oil seal depth: 0 - +0.3 mm (0 - +0.012 in.)**

- (c) Coat the oil seal lips with MP grease.