

FOREWORD

This repair manual covers Disassembly, Inspection and Assembly procedures for the following Automatic Transmissions:

Automatic Transmission	Applicable Model
A340E	'91 Supra, '91 Cressida
A340F	'91 Truck, '91 4 runner
A340H	'91 Truck, '91 4 runner

For On-vehicle Servicing (Inspection, Adjustment, Troubleshooting, Removal and Installation) of Automatic Transmission, refer to the repair manual for the applicable vehicle model.

Pub. Name	Pub. No.
'91 Supra Repair Manual	RM198U
'91 Cressida Repair Manual	RM200U
'91 Truck Repair Manual	RM201U2
'91 4 runner Repair Manual	RM202U2

All information contained in this manual is the most up-to-date at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION