



HOW TO USE THIS MANUAL

Each repair method description provided in Section RE of this manual comprises two pages, divided into 2 blocks (REMOVAL AND INSTALLATION) and includes illustrations to facilitate body repair.



A : REPLACEMENT PART AND METHOD



B : BODY VARIATIONS AND PART LOCATION

Body variations: Non All models

C : REMOVAL DIAGRAM

Describes in detail removal of the damaged part involving repair by cutting.


D : REMOVAL GUIDE

Provides additional information to more efficiently help you perform the removal.

BODY PANEL REPLACEMENT—Rear Body Components

RE-27

INSTALLATION



1. Before temporarily installing the new part, apply body sealer to the wheel arch portion.

NOTE:

- 1) Apply sealer approx. 5 mm (0.20 in.) from the flange, avoiding any oozing.
- 2) Apply evenly, approx. 3 - 4 mm (0.12 - 0.16 in.) in diameter.
- 3) For other sealing points, refer to section SU.

2. Temporarily installing the new part and check the fit of the front door, luggage compartment door and rear combination lamp.

E : INSTALLATION DIAGRAM

Describes in detail installation of the new part involving repair by welding and/or cutting, but excluding painting.

F : INSTALLATION GUIDE

Provides additional information to more efficiently help you perform the installation.

G : SYMBOLS

See page [IN-4](#).

H : ILLUSTRATION OF WELD POINT

Weld method and panel position symbols.
See page [IN-5](#).