





**FRONT FENDER APRON (CUT-H)****REMOVAL**

1. After removing the spot welds, rough cut the front fender apron shown above.

**INSTALLATION**

Cut for supply part



1. Cut the supply part shown above.