




QUARTER PANEL (CUT-P)

REMOVAL






* This section is a cut and join location only.
Refer to [RE-26](#) for weld points.



1. Cut on the line shown above.

INSTALLATION



* This section is a cut and join location only.
Refer to [RE-27](#) for weld points.

1. Before cutting the overlap areas, check the fit for the luggage compartment door and rear combination lamp.
2. Before welding, apply body sealer from inside of the vehicle.

NOTE:

- 1) Do not apply body sealer to the weld seams before welding as the sealer will melt, resulting in a bad seal and a bad weld.

- 2) For other sealing points, refer to section SU.
 3. Surface finish the weld seam from the inside also.
- NOTE: Be careful not to grind off too much weld as it will result in loss of durability.**