





REAR FLOOR PAN (CUT)**REMOVAL**


(LH)

(RH)



1. Cut and join the rear floor pan shown above.
2. Avoid the rear floor side member.
3. Since each bracket is supplied separated, remove the brackets if reusing.

INSTALLATION



1. Cut the new panel shown above.
2. Match the bracket to the new part location (dent marks) and install.
3. After temporarily installing the new part, measure each part in accordance with the body dimension diagram.
4. Plug weld the overlapping portion of the new part.

NOTE: Be sure the portion to be welded are align and not loose.

5. Coat the overlapping opening portion from the both sides with body sealer.