




Code	Part Name	Code	Part Name
53202 53203	Radiator Support Sub-Assy	53723A 53724A	Front Spring Support Reinforcement
53205	Radiator Upper Support Sub-Assy	53801 53802	Front Fender Sub-Assy
53209	Hood Lock Brace Sub-Assy	53899B	Front Fender Panel Support
53257 53258	Front End Panel Mounting Bracket	53932	Front End Panel Sub-Assy
53287B 53288B	Radiator Support Extension	55101	Dash Panel Sub-Assy
53291C	Radiator Support to Frame Seal	55701	Cowl Panel Sub-Assy
53301	Hood Sub-Assy	55713A 55714A	Cowl Top Side Panel
53385A 53386A	Hood Bumper Retainer	55748A	Cowl Top Inner to Pillar Brace
53633	Hood Lock Control Cable Shield	55748A	Cowl Top Inner to Pillar Brace
53701 53702	Front Fender Apron Sub-Assy	57161	Front Crossmember
		—	—



Code	Part Name	Code	Part Name
61103 61104	Front Body Pillar Sub-Assy	61619A	Quarter Panel Reinforcement
61107 61108	Front Body Outer Pillar Sub-Assy	61625E 61626E	Quarter Panel Inner Rear Extension
61211 61212	Roof Side Outer Rail	61631A 61632A	Quarter Wheel Housing Outer Panel
61231 61232	Roof Side Inner Rail	61633A 61634A	Quarter Wheel Housing Inner Panel
61261 61262	Roof Drip Channel	61641B 61642B	Quarter Wheel Housing Gusset
61345B 61346B	Center Body Inner Lower Pillar	61657B 61658B	Quarter Panel End Lower Housing
61347A 61348A	Belt Anchor to Center Pillar Reinforcement	61675B	Rear Suspension Spring Support Reinforcement
61367	Belt Anchor to Center Pillar Lower Reinforcement	61707 61708	Quarter Inner Panel Sub-Assy
61388A 61389A	Center Body Pillar End Plate	61711A 61712A	Roof Side Outer Reinforcement
61411 61412	Rocker Outer Panel	61747 61748C	Roof Side Inner to Wheel Housing Brace
61515A	Quarter Lock Pillar Extension	61766B 61767B	Roof Side Inner to Wheel Housing Brace Reinforcement
61547 61548	Quarter Pillar Inner Reinforcement	61768B	Belt Anchor to Roof Side Inner Rear Reinforcement
61611 61612	Quarter Panel	61769A	Seat Belt Anchor No. 2 Reinforcement
61617A 61618A	Quarter Inner Rear Panel	61773A 61774A	Back Door Opening Lower Patch
		—	—



Code	Part Name	Code	Part Name
51681	Flexible Hose Bracket	57656A	Exhaust Pipe Mounting No. 1 Bracket
57043 57044	Front Side Member Rear Reinforcement	57673	Rear Seat Back Hinge Mounting Bracket
57071 57072	Torque Rod Rear Box Sub-Assy	57737 57747	Differential Support Member Mounting Reinforcement
57101 57102	Front Side Member Sub-Assy	57805	Belt Anchor Reinforcement Sub-Assy
57105A 57106A	Front Side Member Plate Sub-Assy.	58029A	Parking Brake Cable No. 1 Clamp
		58101A	Transmission Auxiliary Cover
		58101F	Mounting Floor No. 1 Bracket
		58102A	Front Floor Reinforcement Sub-Assy
57257	Engine Rear Support Member Bracket	58109A	Parking Brake Retainer Sub-Assy
57401 57402	Main Floor Side Member Sub-Assy	58111	Front Floor Pan
57405A	Center Floor No. 2 Crossmember Sub-Assy	58139A 58149A	Front Floor Side Rear Plate
57407	Center Floor No. 1 Crossmember Sub-Assy		
57417 57418	Front Floor Under Reinforcement	58142	Floor Side Member to Floor Pan Reinforcement
57425 57426	Front Floor No. 2 Reinforcement	58173	Front Floor Stone Deflector
57435 57436	Center Floor Side Member	58183	Front Seat Mounting Inside Bracket
		58193	Instrument Panel Brace Mounting Bracket
57451	Front Floor Crossmember	58207F 58208F	Parking Brake Cable Clamp Sub-Assy
57457C	Front Outside Mounting Front Bracket	58208	Center Floor Pan
57463	Center Floor No. 3 Crossmember	58212C	Center Floor Front Pan
57464	Center Floor Crossmember Strength	58264B	Parking Brake Cable Guide No. 1 Bracket
57465A 57466A	Center Floor Crossmember Rear Gusset	58272B	Belt Anchor to Floor Pan No. 4 Reinforcement
		58273B	Belt Anchor to Floor Pan No. 5 Reinforcement
57467A	Front Seat Outside Mounting Front Bracket	58275C	Wire Harness Protector Bracket
57468A 57469A	Front Seat Outside Rear Bracket	58305	Spare Wheel Clam Bracket Sub-Assy
		58307	Body Lower Back Panel Sub-Assy
		58311E	Rear Floor Service Hole Cover
57475	Front Floor Crossmember Plate	58311	Rear Floor Pan
57523	Center Floor Crossmember Brace	58313F 58314F	Rear Floor Pan to Quarter Panel Extension
57601 57602	Rear Floor Side Member Sub-Assy	58364	Rear Floor Heat Insulator Bracket
57631B 57632B	Rear Floor Side Member Front Reinforcement	58364B	Fuel Tank Support Bracket
		58367	Fuel Tube Clamp Bracket
57648 57649	Quarter Wheel Housing No. 1 Gusset	—	—



Code	Part Name	Code	Part Name
63102A	Windshield Header Panel Sub-Assy	67001	Front Door Panel Sub-Assy
63104	Roof Panel Center Reinforcement Sub-Assy	67002	
63105A	Back Door Opening Frame Sub-Assy	67005	Back Door Panel Sub-Assy
63111	Roof Panel	67111	Front Door Outer Panel
		67112	