




FRONT FENDER APRON (ASSY)

REMOVAL



INSTALLATION



1. Determine the installation position of the new part by the assembly mark.
2. Measurements must be accurate with the body dimension diagram, as this effects the front wheel alignment.

NOTE: The position of the front spring support hole is very important

3. Check the fit of the front fender and hood.