




**RADIATOR UPPER SUPPORT (ASSY)**

**REMOVAL**



## INSTALLATION



1. Temporarily install the new part and measure each part in accordance with the body dimension diagram.

**NOTE:** Install the new panel with the hood lock support.